

Grundlagen

Gateway aktivieren

```
touch /usr/local/HMLGW  
reboot
```

Gateway deaktivieren

```
rm -f /usr/local/HMLGW  
reboot
```

From:

<https://wiki.mahlen.biz/> - **Smart-Home Wiki**

Permanent link:

https://wiki.mahlen.biz/doku.php?id=homematic:homematic_grundlagen

Last update: **17.09.2025**

